



onstrukt



TURN THE REAR CAP COUNTER CLOCKWISE TO REMOVE BATTERY CAGE, LOAD BATTERIES, PLACE CAGE BACK IN THE REAR OF THE TORCH, REPLACE THE CAP, DON'T OVERTIGHTEN



PRESS FULLY UNTIL SWITCH 'CLICKS' ONCE TO TURN ON
PRESS HALF WAY TO CHANGE FROM HIGH TO LOW
PRESS FULLY UNTIL SWITCH 'CLICKS' ONCE TO TURN OFF

ON/OFF, HIGH/LOW
SWITCH



+ AND - INDICATE THE CORRECT
DIRECTION OF THE BATTERIES TO BE
INSTALLED.



ONLY EVER USE BATTERIES OF THE SAME
TYPE AND AGE. NEVER MIX BATTERIES

